

DR-1 V1.10 Update Information

New Feature

1. SOURCE select function for the effect to be added
You can select whether the effect is applied to the input signal (INPUT) or the playback signal (PLAY).
The default setting is PLAY.
2. LR SWAP function for the built-in microphones to be added
If you stand the unit and angle the built-in mics toward the front of the unit, the stereo position of the recording might be reversed from that of the source.
In such cases, set SR SWAP to R-L to record with correct stereo positioning.
The default setting is L-R.
3. Monitor setting when Tuner is on
When TUNER is on, the input monitor will be activated automatically even if MONITOR setting in the INPUT SETTING is set to OFF.
When you exit the tuner mode, MONITOR setting will be resumed (follow the MONITOR setting in the INPUT SETTING).
4. Default setting of Contrast
The default setting of Contrast is changed from 12 to 8.

How to update the firmware

1. Save the latest firmware updater file ("DR-1_16.110") on your PC.
2. Connect the DR-1 (with SD card) to your PC via USB cable. PC will recognize the DR-1 as external memory device.
3. Copy the firmware updater file ("DR-1_16.110") to the "UTILITY" folder of the DR-1.
4. After the file saved correctly on the DR-1, disconnect the DR-1 from PC, remove the USB cable, then turn off the power.
5. Hold the MENU key and >/II key then turn on the power. The update mode is launched.
 - * If the update mode is not launched, turn off the power then retry No.5 procedure.
 - * Keep holding the keys until the mode is launched.
 - * If there is (are) firmware updater file(s) in this folder, all firmware updater files are listed. If there is no firmware updater file, "No Update File" message is appears.
6. Select the updater file (DR-1_16.110) by the wheel

then press >/II key. The current firmware version and new firmware version will appear on LCD.

7. Press >/II to begin the update.
8. After the update is completed, the power will be turned off automatically.
9. Check the system version
 - 9-1. Press the MENU key to enter the menu mode. Select "INFORMATION" by the wheel, then press >/II key.
 - 9-2. Select "SYSTEM (3/3)" by the wheel. The system version is shown on the LCD.
10. Connect the DR-1 to your PC via USB, then remove the updater file from "UTILITY" folder.

[NOTE]

When you update the unit, the battery should be charged enough otherwise the update procedure cannot complete successfully.